archer² archer³
connectorprotector

Installation Instructions

The Archer connector protector kit provides extra protection for the ports in the I/O Module on the bottom of the handheld. It works with both the Archer² and the Archer³.

Kit Number: 24690

Contents of the Archer²/Archer³ Connector Protector Kit

The connector protector kit includes:

- Connector protector
- Instruction sheet

Installation Instructions

The large end of the connector protector is inserted into the connector module. The smaller end is the retention end.

1. Power off the handheld.

2. The connector protector is installed from the battery compartment, which is accessed from the back of the handheld. Loosen the four captive screws holding the battery compartment door in place using a #1 Phillips screwdriver. Remove the door.

⚠ **CAUTION:** The handheld is not sealed against water and dust when the battery door is not installed.

3. If you are replacing an existing connector protector, pull it off of the connector module and peel the retention end free.

4. To install the new connector protector, insert the retention end into the area underneath the connector module. Press it underneath the battery door screw holes as shown.

5. When the retention end is installed correctly, it will look like the following photo. Make sure that the battery door gasket is seated in place along the edges as indicated.

6. Place the Li-Ion battery pack in the compartment. Make sure the symbols on the battery pack label align with the symbols inside the compartment.

7. Re-install the battery door and tighten the screws. The door holds the connector protector in place.

8. Place the connector protector into the connectors as shown.