

Charging Information

- The Geode GNS1 or GNS2 can be plugged in over nights and weekends to ensure you have a full battery at the beginning of each work day.
- If you do not use the Geode every day, it can be left plugged in for up to two weeks.
- If you are going to store the Geode for more than two weeks without plugging it in, ensure the Geode has a full battery. In this case, we recommend plugging it in at least once a month.

Note: If the Geode becomes over-discharged you will need to send it in for repair.

tel: 435.753.1881 | web: www.junipersys.com

1132 W. 1700 N. Logan, UT 84321
