

Grounded Stylus for Mesa 4

The grounded stylus is a wired stylus that plugs into the power input jack on the Mesa 4. This stylus works well in harsh, cold weather conditions and allows the user to wear gloves while using the touchscreen.

To install the grounded stylus,

1. Remove the connector cover from the ports.
2. Gently pull the curved rubber retainers from the holes where they are seated.


Note: Keep the connector cover for future use.



3. Insert the new connector cover.



4. Insert the stylus connector into the power input jack.



5. Loop the stylus cable around the hand strap to keep it from pulling out of the power input jack during use.
6. Place the stylus in the holder on the hand strap when not in use.

Note: You can purchase a hand strap with a stylus holder from the [Juniper Systems store](https://www.junipersystems.com).

