

Regulatory Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Changes or modifications to this product not authorized by the manufacturer could void the radio frequency compatibility and wireless compliance and negate your authority to operate the product. The use of non-compliant peripheral devices could cause the emission of radiation is are not within the limits set by part 15 of the FCC rules. Only use peripheral devices that have been tested to provide electromagnetic compatibility when connected to this unit.

Exposure to Radio Frequency (RF) Signals

Your device contains a radio transmitter and receiver. The radiated output power is far below the international radio frequency exposure limits. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on the safety standards previously set by international standards bodies:

- American National Standards Institute (ANSI) IEEE. C95.1-1992
- National Council on Radiation Protection and Measurement (NCRP). Report 86. 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1996
- Ministry of Health (Canada), Safety Code 6.

The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in usage.


As with other mobile radio transmitting equipment, users are advised that for satisfactory operation of the equipment and for the safety of personnel, it is recommended that no part of the human body be allowed to come too close to the antenna during operation of the equipment.

Your device has an internal antenna. Use only the supplied integral antenna. Use of unauthorized or modified antennas may impair call quality and damage the phone, causing loss of performance and SAR levels exceeding the recommended limits as well as result in non-compliance with local regulatory requirements in your country.

To assure optimal phone performance and ensure human exposure to RF energy is within the guidelines set forth in the relevant standards; always use your device only in its normal-use position. Do not touch or hold the antenna area unnecessarily when placing or receiving a phone call. Contact with the antenna area may impair call quality and cause your device to operate at a higher power level than needed. Avoiding contact with the antenna area when the phone is IN USE optimizes the antenna performance and the battery life.



CT4_QSGRev01 1408

QUICK START GUIDE FOR CEDAR TREE TECHNOLOGIES CT4 HANDHELD




Cedar Tree Technologies
1220 NW Kings Blvd • Corvallis, OR 97330 • 541-230-1206
support@cedartreetechnologies.com • www.cedartreetechnologies.com/support


Buttons and ports



Installing A SIM or SD Card



What's In The Box



Support
Web: www.cedartreetechnologies.com/support
Email: support@cedartreetechnologies.com

Cedar Tree Technologies
1220 NW Kings Blvd • Corvallis, OR 97330 • 541-230-1206
sales@cedartreetechnologies.com • www.cedartreetechnologies.com

Installing a SIM card

- 1) Orient device as shown in the figure at lower left.
 - 2) Using the provided screwdriver tool loosen the two screws (1) on the rear port cover by turning them counter-clockwise.
 - 3) Carefully lift and remove the rear port cover with the provided screwdriver tool
 - 4) Locate SIM Slot 1 in figure at lower left
 - 5) Orient the SIM Card 1 as shown so that the contacts are down and the notch is on the right
 - 6) Gently push SIM Card 1 into the device with the provided tool until it is fully seated. NOTE: Forcing the card into or out of the slot could damage the unit. If the card does not seat properly or does not function correctly, check the card orientation and try again. SIM Slot 2 is available for customers who intend to be connected to two cellular networks simultaneously. To use this feature, rotate SIM Card 2 as shown below left so the contacts are up and the notch is on the left before insertion into the slot.
 - 7) To remove SIM cards, gently pull on the SIM card with tweezers or your fingernail until it slides free of the slot.
 - 8) Replace the rear port cover by aligning the three tabs on the cover with the slots in the case.
 - 9) Using the provided tool, tighten the two screws (1) on the rear port cover by turning them clockwise until the cover is fully seated. Screws should be snug but over-tightening the screws can damage the unit.
- NOTE: The CT4 only accepts full-sized SIM cards. If your cellular carrier provides you with a micro SIM, you will need to insert the micro SIM into a SIM card adapter before using it in your device.

Installing an SD card

- 1) Orient device as shown in the figure at lower left.
 - 2) Using the provided screwdriver tool loosen the two screws (1) on the rear port cover by turning them counter-clockwise.
 - 3) Carefully lift and remove the rear port cover with the provided screwdriver tool
 - 4) Orient the SD card as shown so that the contacts are down and the notch is on the left.
 - 5) Gently push the SD card into the device with the provided tool until it is fully seated. NOTE: Forcing the card into or out of the slot could damage the unit. If the card does not seat properly or function correctly, check the card orientation and try again.
 - 6) To remove the SD card, gently pull on the SD card with tweezers or your fingernail until it slides free of the slot.
 - 7) Using the provided tool, tighten the two screws (1) on the rear port cover by turning them clockwise until the cover is fully seated. Screws should be snug but over-tightening the screws can damage the unit.
- NOTE: The CT4 only accepts microSD cards. Larger SD cards (i.e. full-sized or miniSD) are not compatible with this unit.

WARNING: Ensure that the audio, USB, and rear port covers are clean and securely seated before exposing the unit to water. Failure to perform this step could lead to water damage of the unit.

Initial Power Up

- 1) Press the Power (2) button (2) for 3 seconds and wait for the device to boot
- 2) Swipe the screen from left to right to unlock the device. The SIM management app will automatically launch.
- 3) On the SIM card changed screen tap **Change**
- 4) On the SIM management screen tap **Data connection** and then tap the button next to your SIM. This will activate the data connection for the newly inserted SIM.
- 5) A quick press of the Power (2) button (2) will turn off the display. To fully power down the device, press the Power (2) button (2) for 3 seconds and tap **Power off**.

NOTE: After impact or extended underwater use, the device may become unresponsive. To recover, power the device off and back on. If the device is still unresponsive, charge for ten minutes before powering on.

Adding your Google Account

- 1) Press the Home (3) button (3)
- 2) Press the Menu (4) button (4)
- 3) Tap **System settings**
- 4) Scroll down to **Accounts** and tap **Add an account** on the Settings screen
- 5) Tap **Google** on the **Add an account** screen
- 6) Follow the instructions to setup your Google account

Indicators



NOTE: Data speed is indicated by a small superscript above each cellular icon. H (HSPA) is the highest data speed followed by 3G, E (edge) and G (GPRS). The warning (1) 'Slot 2:No SIM card detected' can be ignored if using only one SIM.

Connect to Wi-Fi

- 1) Press the Home (3) button (3)
- 2) Press the Menu (4) button (4)
- 3) Tap **System settings**
- 3) Tap the OFF icon next to **Wi-Fi** to turn **WLAN** on. The **Wi-Fi** indicator (1) will appear at the top of the display and **Wi-Fi** will read **ON**.
- 4) Tap **Wi-Fi** to view the list of nearby access points
- 5) Tap on the access point you wish to connect to. Enter any required passwords to gain access to the WLAN network.

Connect a Bluetooth device

- 1) Press the Home (3) button (3)
- 2) Press the Menu (4) button (4)
- 3) Tap **System settings**
- 3) Tap the OFF icon next to **Bluetooth** to turn Bluetooth on. The Bluetooth indicator (1) will appear at the top of the display and Bluetooth will read **ON**.
- 4) Tap **Bluetooth** to view the list of nearby Bluetooth devices
- 5) Tap on the device you want to access
- 6) NOTE: If you are connecting another device to the CT4, tap **Not visible to other Bluetooth devices** to make your device temporarily discoverable.

Accessing Applications

- 1) Press the Home (3) button (3)
- 2) Tap the Apps (1) icon at the bottom of the Home screen
- 3) All applications installed on your device will be shown.
- 4) Tap and hold any application icon to create a shortcut on the Home screen.
- 5) Tap **Play Store** (on the second Apps screen) to locate and install new applications.

Accessing Widgets

- 1) Press the Home (3) button (3)
- 2) Tap the Apps (1) icon at the bottom of the Home screen
- 3) Tap the **Widgets** tab at the top of the Apps screen
- 4) All widgets installed on your device will be shown.
- 4) Tap and hold any widget icon to create a shortcut on the Home screen.
- 5) Tap **Play Store** (on the second Apps screen) locate and install new widgets.

Sending a Text Message

- 1) Press the Home (3) button (3)
- 2) Tap on the **Messaging Icon** (1) on the Home screen
- 3) Tap on the plus symbol at the bottom left of the Messaging screen
- 4) Enter the phone number of the person you are texting in the 'To' box
- 5) Type the text message
- 6) Tap the send icon (paper airplane) at the bottom right

Operating the Camera

- 1) Press the **Camera** button (5)
- 2) Compose the photo by tapping the Camera screen with two fingers and sliding them apart to zoom. Slide them together (pinching) to zoom out.
- 3) Tap the **Lightning** icon at the bottom right to turn flash on, off, or auto.
- 4) Tap the **Camera** icon (1) at the bottom right to use the front facing camera
- 5) Press the **Camera** button (5) or circular **Shutter** icon at the bottom right of the display to take a still photo
- 6) You can capture video with sound by tapping the **Video** icon at the bottom-left of the display. NOTE: The video files will be stored on the SD card.
- 7) Additional settings are available using the icons at the top of the Camera screen. Tap the **Gear** icon to access advanced camera settings.

NOTE: Use only the supplied Micro USB cables for charging the device and transferring data. Some existing USB cables will not charge the device because the barrel is too large, or the connector is too short.